



TECHNICAL CATALOGUE















ITAP SpA, founded in Lumezzane (Brescia) in 1972, is currently one of the leading production companies in Italy of valves, fittings and distribution manifolds for plumbing and heating systems. Thanks to fully automated production processes, with 72 tooling machines and 51 assembly lines, we are able to produce 200,000 pieces per day. Our innate pursuit for innovation and observance of technical regulations is supported by the company certification ISO 9001: 2008. The company has always considered its focus on quality as the main tool to obtain significant business results: today ITAP SpA is proud to offer products bearing the approval of numerous international certifying bodies.



ROMA® CHECK VALVE

SUITABLE FOR DOMESTIC WATER SERVICES, HEATING AND AIR-CONDITIONING PLANTS, COMPRESSED AIR SYSTEMS.

THEY CAN BE INSTALLED IN ANY POSITION: VERTICAL, HORIZONTAL, OBLIQUE.

SUITABLE FOR USE WITH GASOLINE AND FUELS IN GENERAL.

104

ROMA® CHECK VALVE

SIZE	PRESSURE	CODE	PACKING
3/8" (DN 10)	25bar/362.5psi	1040038	10/100
1/2" (DN 15)	25bar/362.5psi	1040012	10/100
3/4" (DN 20)	25bar/362.5psi	1040034	8/72
1" (DN 25)	25bar/362.5psi	1040100	6/48
1"1/4 (DN 32)	18bar/261psi	1040114	4/28
1"1/2 (DN 40)	18bar/261psi	1040112	4/24
2" (DN 50)	18bar/261psi	1040200	2/16

TECHNICAL SPECIFICATIONS

Body in brass.

Plate in stainless steel. Washer in Viton[®].

Spring in stainless steel.

Outlet plugs in brass, thread 1/4".

Minimum working temperature: -20°C.

Maximum working temperature: 100°C with water ;

150°C with fluid hydrocarbons or compressed air.

Threads ISO228 (equivalent to DIN EN ISO 228 and BS EN ISO 228).

CERTIFICATIONS	ERE ERE ERE 🛦 🛞 🖬 🏡 🕬	0%

MATERIALS



POS.	DESCRIPTION	N.	MATERIAL
1	Body	1	Brass CW617N
2	Pin	1	Brass CW614N
3	Spring	1	Stainless steel AISI 302
4	Plate	1	Stainless steel AISI 304
5	Washer	1	VITON [®]
6	Plug	1	Brass CW614N
7	End adapter	1	Brass CW617N
8	Washer	2	Aluminium
9	Plug	2	Brass CW614N







	3/8″	1/2″	3/4″	1″	1″1/4	1″1/2	2″
DN	10	15	20	25	32	40	50
А	63	68,5	69,5	79 84		93,5	108
В	47,3	47,3	54,5	60,8	72,8	83,3	99,3
С	10	13,5	14	15	16	16	20
D	10	14	14	15	15,5	17	19
Kg/cm² bar	25	25	25	25	18	18	18
LBS - psi	362,5	362,5	362,5	362,5	261	261	261

MANIFACTURER INSTRUCTIONS

Installation

The ROMA® check valves are uni-directional; that means they manage the flow in one direction only, which is indicated by the arrow on the body. The valves are composed by a spring, a little valve and a couple of parts made of brass (body and end-adapter) which contain them and that are assembled by means of thread and a sealed material to obtain their aim. In order to avoid that the sealed material gets broken and then the valve looses the connection between the body and the end-adapter, it's necessary to avoid to submit the two parts under the influence of a torque. For the installation normal hydraulic practices must be used, and especially:

- For a proper installation of the valve, near curves and circulation pumps, the valve must be mounted at a distance equal to 10 times the diameter of the pipe.

- The installer has to be sure that the two pipes are correctly aligned;

- During the assembling process the installer has to apply its assembling tools at the end that is nearest to the pipe;

- The application of the sealing materials by the fitter (PTFE or hempen cloth) must be limited at the thread zone. An excess should interfere in the ball gasket's closure zone, compromising the tightness;

-In case the fluid transported has got some impurities (dust, too hard water, and so on) it's necessary to remove impurities by or filter them, otherwise they could damage the seal.

Disassembly the installed valve

To remove the valve from the pipe line or anyhow before unscrewing the connections linked:

- Wear the protective clothing normally required to work with carried fluids;
- Depressurizze the line;
- During the disassembling process, apply the key at the end of the valve, the one nearest the pipe

Maintenance

Verify the valve periodically, according to its application's field and its works' field and its work's conditions, in order to be sure that the valve works correctly. In case of losses of tightening, take note that these can be caused by a deposit of foreign bodies (dirty, calcareous) on the rubber seal. In order to solve this inconvenient, it's necessary to unmount the valve and remove the foreign body with compressed air tools.

FLOW RATE AND PRESSURE DROP CHART



WITH WATER

Dates given by laboratory CETIM acrredited by RNE

ROMA® CHECK VALVE





2

TF(

102												
STRAINER FOR FUROPA® VORK®			2					SIZE		CODE	PACK	ING
$ROMA^{\mathbb{B}}$, $BIOCK^{\mathbb{B}}$			Kenne					2/0// /DN 4	0)	4020020	20/11	
CHECK VALVES			C. Mars	10,0° 5 6 1	9.AX			3/8" (DN 1	5)	1020038	30/12	200
			1000	anna a' Ca	884V		_	2/4" (DN 2	0)	1020012	30/9	•0
			1.100	card.	23X		_	3/4 (DN 2) \	1020034	20/4	00 00
			公 任初	200	6.1			1"1/4 (DN 3	, 22)	1020100	10/1	80
			1.1.2	10233	34			1"1/2 (DN 4	10)	1020112	10/1	40
			188310	0000	223			2" (DN 50)	1020712	4/7	40
			1883		88N			2"1/2 (DN /	5)	1020200	1/6	2
			88005	2000	XXX			3" (DN 80)	1020202	1/3	6
			1000	66660	120			4" (DN 100	י אר	1020300	1/3	0
								4 (DN 10	,	1020400	1/2	0
SPECIFICATIONS	- 3/8 - 2"1 Strai Thre Thre Avai	" throu /2 thro ner in aded ad: ISC Iable	ugh 2": ough 4 stainle end in D228 (e also w	1200µ 4": 2000 ess stee polym equival ith NP	im; Jµm. Jel. Jer. Jent to F threa	DIN EP ad in th	N ISO 2 ne size:	28 and 5 2″1/2	BS EN , 3″ e 4	1 ISO 22 F".	28).	
CERTIFICATIONS	ERE	ERE ER		•	<u>\$</u>							
MATERIALS												
OVERALL DIMENSIONS												
				1					A			
			3/8″	1/2″	3/4″	1″	1″1/4	1″1/2	2″	2/″1/2	3″	4″
		А	42	47	57,5	69	75	83	98	123	138	152,5
		В	25,5	29,5	36	43,5	50,5	56,5	69	86	102	129
	POS.	DESCR	RIPTI <u>ON</u>			N. MATE	RIAL					

1

Stainless steel AISI 304

ROMA® CHECK VALVE

2

Strainer

UROPA®, YORK®, ?OMA®, BLOCK®						c	75	CODE	RACKING
CHECK VALVES		9		2		3		CODE	FACKING
1				5		3/8" (DN 10)	1070038	50/1500
				3		3/// (DN 20)	1070012	35/8/0
- 			-	5		3/4 (1″ (Г	DN 25)	1070034	30/420
 			-	3		1″1/4	(DN 32)	1070114	20/280
				5		1"1/2	(DN 40)	1070112	15/195
			-	3		2" ([DN 50)	1070200	8/112
CERTIFICATIONS MATERIALS OVERALL DIMENSIONS	ERE						A		
							•		
			3/8″	1/2"	3/4"	1"	1″1/4	1"1/2	2"
		A	3/8" 55,5	1/2″ 55	3/4 ″ 55,3	1″ 59	1″1/4 69,5	1″1/2 74	2″ 87,3
		A B	3/8″ 55,5 23	1/2″ 55 25	3/4 ″ 55,3 32	1 ″ 59 39	1″1/4 69,5 47	1"1/2 74 54	2″ 87,3 66
		A B C	3/8″ 55,5 23 1	1/2″ 55 25 1	3/4 " 55,3 32 1	1 ″ 59 39 1	1″1/4 69,5 47 1	1″1/2 74 54 1	2″ 87,3 66 1
		A B C D	3/8″ 55,5 23 1 5,58	1/2″ 55 25 1 8,15	3/4 " 55,3 32 1 11,37	1 ″ 59 39 1 14,74	1″1/4 69,5 47 1 20,78	1"1/2 74 54 1 23,94	2" 87,3 66 1 30,99
		A B C D E (n°)	3/8″ 55.5 23 1 5,58 52	1/2″ 55 25 1 8,15 52	3/4 ″ 55,3 32 1 11,37 52	1 ″ 59 39 1 14,74 52	1″1/4 69,5 47 1 20,78 56	1″1/2 74 54 1 23,94 64	2″ 87,3 66 1 30,99 76
		A B C D E (n°)	3/8" 55,5 23 1 5,58 52	1/2″ 55 25 1 8,15 52	3/4 " 55,3 32 1 11,37 52	1 ″ 59 39 1 14,74 52	1"1/4 69,5 47 1 20,78 56	1″1/2 74 54 1 23,94 64	2″ 87,3 66 1 30,99 76
		Α Β C D Ε (n°) Filtration (μ)	3/8″ 55,5 23 1 5,58 52 1.000	1/2" 55 25 1 8,15 52 1.000	3/4 ″ 55,3 32 1 11,37 52 1.000	1 ″ 59 39 1 14,74 52 1.000	1"1/4 69,5 47 1 20,78 56 1.000	1"1/2 74 54 1 23,94 64 1.000	2″ 87,3 66 1 30,99 76 1.000
		Α Β C D E (n°) Filtration (μ)	3/8" 55,5 23 1 5,58 52 1.000	1/2" 55 25 1 8,15 52 1.000	3/4 " 55,3 32 1 11,37 52 1.000	1 ″ 59 39 1 14,74 52 1.000	1″1/4 69,5 47 1 20,78 56 1.000	1"1/2 74 54 1 23,94 64 1.000	2" 87,3 66 1 30,99 76 1.000
	POS. DE	Α Β C D E (n°) Filtration (μ)	3/8″ 55,5 23 1 5,58 52 1.000	1/2" 55 25 1 8,15 52 1.000 N.	3/4" 55,3 32 1 111,37 52 1.000	1 " 59 39 1 14,74 52 1.000	1"1/4 69,5 47 1 20,78 56 1.000	1"1/2 74 54 1 23,94 64 1.000	2 " 87,3 66 1 30,99 76 1.000

We reserve the right to make improvements and changes to the products described herein and to the relative technical data, at any time and without forewarning.



ITAP S.p.A. Via Ruca 19 25065 Lumezzane Brescia (ITALIA) Tel 030 89270 Fax 030 8921990 www.itap.it-info@itap.it